

Temporary Check Dam

Ultra-Silt Dike is an effective stormwater management tool that provides erosion control and helps keeps your jobsite in compliance. When used as a check dam, it offers temporary stormwater and sediment control for ditches and swales. It can also be used as perimeter control, preventing stormwater and sediment from escaping from exposed construction areas. Ultra-Silt Dike is a reusable alternative to silt fence and straw bales. It is lightweight and easy to transport. Installation is quick with no heavy equipment needed. Larger coverage areas can be created simply by installing sections end-to-end.



Temporary Check Dam



Features

- Interior: Foam Urethane
- Exterior: Woven Poly Geotextile
- Available in 7' Sections, Choice of Green or Black Fabric
- Install End-To-End for Larger Coverage Areas

Benefits

- Easy, Quick Installation
- Use for Check Dams, Filtration, Perimeter Erosion Control
- Economical and Reusable
- Flexible and Lightweight

We are here to serve you. Just call or email with your project specifications and details, and we'll do the rest. Our goal is to provide the best solution for your project, with materials delivered on time at a price that fits nicely within your budget.



Temporary Check Dam

| Part # | Color | Dimensions | Weight |
|--------|-------|-------------------|----------|
| 9712 | Black | 84" × 67" × 10.5" | 8.0 lbs. |
| 9715 | Green | 84" × 67" × 10.5" | 8.0 lbs. |

Material Specifications:

| Properties | ASTM Test | V alue | | |
|---|-----------|--------------------------------|--|--|
| Geotextile Fabric / Material: Woven, Polypropylene Geotextile | | | | |
| Grab Tensile (lbs) | D 4632 | 180/105 | | |
| Elongation (%) | D 4632 | 20/15 | | |
| Trapezoid Tear (lbs) | D 4533 | 85/75 | | |
| Puncture (lbs) | D 4833 | 70 | | |
| Mullen Burst (psi) | D 3786 | 325 | | |
| Permittivity (sec^-I) | D 4491 | 0.25 | | |
| A.O.S. (U.S. sieve no.) / Microns | D 4751 | 40 / 420 | | |
| UV Stability (strength retained %) 500 hrs | D 4355 | 80 | | |
| Urethane Foam / Material: Woven, Polypropylene Geotextile | | | | |
| Density lbs/ft³/min | D 3574-95 | 1.00 +/-0.1 | | |
| Indent Force Deflection at 25% deflection (4 inch specimen) | D 3574-95 | 30 +/- 3lbs/50 in ² | | |
| Tensile Strength psi min | D 3574-95 | 10 | | |
| Elongation % min | D 3574-95 | 125 | | |
| Tear Resistance Ibs/lin. inch | D 3574-95 | 1.25 | | |
| Comp. Set @ 50% comp. | D 3574-95 | I0% max | | |

We are here to serve you. Just call or email with your project specifications and details, and we'll do the rest. Our goal is to provide the best solution for your project, with materials delivered on time at a price that fits nicely within your budget.



Temporary Check Dam

Ultra Silt Dike - Additional Products

| Part # | Model | Quantity |
|--------|------------------|-------------|
| 9714 | U-Shaped Staples | Box of 1000 |

Installation Process:

Step 1:To start this simple and easy process, place the Silt Dike at the installation location.

Step 2: Once you have the Silt Dike product in place, make sure it is sitting flush with the ground so that no water can escape without going through the filter.

Step 3: Now you can insert the U-shaped wire staples (not included) into the Silt Dike's apron. Make sure the staples go through the apron and into the soil, so the product is secured.

Other Options:







Spring Berm

Composite Filter Sock

Coir Wattle

For more complete information on One Clarion products and solutions, visit us on the Web at www.clarionmunicipal.com.

Phone: (+1) 863-261-8388 | info@oneclarion.com

© 2024 One Clarion. All rights reserved. One Clarion terms and conditions apply.

All photos are representative only. Actual products may differ. Materials and specifications are subject to change without notice. Featured products in photos may include additional equipment or accessories.

